COMPONENT SETTINGS

Driver: Select OPAMP Drivers:OPAMP:Basic

1-Single: OP0, OP1, OF Combination:

CLOCKS

OPAMP:

Main Clock (CLK MAIN) (2