


mikroBUS INTERFACE CONNECTORS



NOTE: Only install R3 (3.3V) or R4 (5V) but not both. Default is 3.3V with R3