



Connect a multimeter to measure the resistance between pins **P1W** and **P1A**