

CxTXQUA = 0x1A8


CxTXQSTA:

TXQEIF = 0

TXQNIF = 1

CxTXQCON :

TXREQ = 0



MO0/MSG2
MO1/MSG1
MO2/MSG3
MO3/MSG4
MO4/MSG5
MO5/MSG6
MO6/MSG7
MO7