
CURRENT MEASUREMENT HEADER
SW0 USER BUTTON
SW1 USER BUTTON
DEBUG USB
USER LED0
POWER HEADER
UPDI DEBUG FOR EXTERNAL DEBUGGER
MCU CURRENT MEASUREMENT SELECT JUMPER
I/O CURRENT MEASUREMENT SELECT JUMPER
ATTINY3217
EXTENSION 1 HEADER
QTOUCH® BUTTONS
32.768 kHz CRYSTAL
EXTENSION 3 HEADER
GND
AVR
SW0
SW1
LED0
DEBUG USB
POWER
STATUS
PWR
5.0V_IN
GND
5.0V
VCC
ATTINY3217 UPDI DEBUG
MEASURE
BYPASS
CURRENT MEASUREMENT
MICROCHIP
ATTINY3217 XPLAINED PRO
QT BTN 1
QT BTN 2
32kHz CRYSTAL
EXT1
EXT3
ID
PA6 PA7
PB0 PB1
PA5 PA4
PA1 PA2
PB3 PB2
PC3 PC2
PC1 PC0
GND VCC