
mikro BUS
J21
J22
J23
AN
RST
CS
SCK
MISO
MOSI
+3.3V
GND
PWM
INT
RX
TX
SCL
SDA
+5V
GND
1
2
3
J14 port-B
J13 port-A
ETHERCAT
MICROCHIP
J11 Ethernet port 1
J12 Ethernet port 2
J10 Gigabit Ethernet
WIFI/BLE
SAMA5D2-ICP
rev.2
INDUSTRIAL CONNECTIVITY PLATFORM
USB
JTAG
JLINK
USER_PB1
DIS_BOOT
USER_PB2
SW4
SW2
SW5
SW3
SW1
START
RESET
5V DC
U4
VDDBU
HSIC status
User LED
USB suspend
DISABLE J-LINK OB
DISABLE J-LINK CDC
ERASE
UART_RX
UART_TX
WILC activity
GPIO17
GPIO18
GPIO19
GPIO20
GPIO0
GPIO21
3V3