```
C:\Microsemi\DFKDB>"%nfast_home%\python\bin\python.exe" C:\Microsemi\Tools\gensymmkey.py -u
userdata-signer -i g4mcu-1000000000000000000000000000000000000002
==============================================================
= Generating symmetric key with ExportAsPlain enabled
=
= KeyIdent:      simple/g4mcu-1000000000000000000000000000000000000002
= KeyHash:       8b8de231 a7dc5a7c 4ae4484d c6c0d8a9 2816432a
=   SEE App KeyIdent:  seeinteg/userdata-signer
=   SEE APP KeyHash:   72ae1996 3f2f9a88 e49babb0 9ffb0393 28c94f3a
=
= Open group perms:  DuplicateHandle|ReduceACL|GetACL
= SEE App perms:     ExportAsPlain|GetAppData
==============================================================
```