
File
Edit
Selection
View
Go
avr32la32_cnano_getting_started
Sign In
EXPLORER
AVR32LA32_CNANO_GETTING_STARTED
.vscode
config.mcc
main.c
README.md
OUTLINE
TIMELINE
MCC: config
Project Resource
Device Resource
Generate
Content Manager
Project Resources
MCC v5.7.0
Drivers
Timer
TCB0
UART
UART0
System
CLKCTRL
Configuration Bits
Interrupt Manager
Main
Pins
Pin Package View
Application Builder
Layouts
Zoom
Info
Settings
Save Image
Add Component
Legends
Main
UART0
USART0_Peripheral
TCB0
System
CLKCTRL
Interrupt Manager
Configuration Bits
Pins
AVR32LA32
AC 1
ADC 1
BOD 1
CCL 1
CPU 1
CRCSCAN 1
EVSYS 1
NVMCTRL 1
RSTCTRL 1
RTC 1
SLPCTRL 1
SPI 1
SYSCFG 1
TCB 2
TCE 1
TWI 1
USART 1
VREF 1
WDT 1
MICROCHIP
AVR32LA32
Pins
TCB0
UART0
Log
User Output
Notifications
Pin Grid View
0
0
MPLAB
Autocomplete (NE)