Address	Device		
00 0000h	PIC18Fx4Q40	PIC18Fx5Q40	PIC18Fx6Q40
to	Program Flash Memory (8KW) ⁽¹⁾	Program Flash	
00 3FFFh	(OIXVV)	Memory	
00 4000h to		(16 KW) ⁽¹⁾	Program Flash Memory
00 7FFFh			(32 KW) ⁽¹⁾
00 8000h			
to 00 FFFFh	Not		
01 0000h	Present ⁽²⁾	Not	
to		Not Present ⁽²⁾	
01 FFFFh		1 1000111	Not Present ⁽²⁾
02 0000h to			Present
1F FFFFh			
20 0000h	Heart IDs (22 Words)(3)		
to 20 003Fh	User IDs (32 Words) ⁽³⁾		
20 0040h	Decemend		
to 2B FFFFh	Reserved		
2C 0000h			
to 2C 00FFh	Device Information Area (DIA) ^(3,5)		
2C 0100h			
to	Reserved		
2F FFFFh 30 0000h			
to	Configuration Bytes ⁽³⁾		
30 0009h 30 000Ah			
to	Reserved		
37 FFFFh 38 0000h			
to	Data EEPROM (512 Bytes)		
38 01FFh 38 0200h			
to	Reserved		
3B FFFFh 3C 0000h			
to	Device Configuration Information ^(3,4,5)		
3C 0009h			
3C 000Ah to	Reserved		
3F FFFBh			
3F FFFCh to	Revision ID (1 Word) ^(3,4,5)		
3F FFFDh			
3F FFFEh	0(3.4.5)		
to 3F FFFFh	Device ID (1 Word) ^(3,4,5)		
Netec 4	Storage Area Flash is implemented as the last 128 Words of User Flash, if enabled.		
	The addresses do not roll over. The region is read as '0'.		
	Not code-protected.		
4.	Hard-coded in silicon.		
5.	This region cannot be written by the user and it is not affected by a Bulk Erase.		